

Installation instructions: ANC-AB2DC

Material typically required to complete installation: ANC-AB2DC, Velcro with psa or self-tapping screws appropriate for substrate (optional)

1. For each door panel cover
2. Match the Velcro with PSA (provided in shipment) to the Velcro sewn onto the door panel
3. Lightly mate the two Velcro's (note: attaching too firmly will make removal of door panel cover difficult)
4. Position door panel cover so that top of door panel cover aligns with top of door frame and is centered in area to be covered (gaps between the door and floor or door jam should be covered by door panel cover)
5. Make incision or cutout in barrier patch for knob/handle.
 1. Starting at the top of the door panel cover
 - i. Remove the paper backing from the PSA Velcro and secure Velcro to the existing door
 2. Be sure door is clean and free from debris
6. Remove door panel cover leaving PSA Velcro adhered to the existing door
7. Ensure that the PSA Velcro is fully adhered to the existing door surface
 1. Use a straight edge to run over the Velcro to set the psa onto the existing door surface
8. Secure acoustical door panel cover to existing door via mating Velcro
9. Secure with additional mechanical fasteners as needed