

Installation instructions: ANC AB12

Material typically required to complete installation: ANC AB12 Acoustical Panels and hardware

1. Assemble hardware according to appropriate directions
2. Insert 16 NR 1 ½" roller hooks provided thru grommets in each curtain panel.
 1. NOTE: Due to the thickness of some types of Acoustical Curtain Panels you may need to pry open roller hooks slightly before installing thru grommet. Crimp roller hooks tightly to curtain after installing thru grommet
3. Referring to the panel layout drawing for panel positions and taking care to note which direction the panels face to insure Velcro seals mate properly.
 1. Install panels
 - i. Lift curtain panels up to the open end of the track; feed wheels of roller hooks into track.
 - ii. Each progressive panel should overlap the previous section by approximately 2". Secure pieces in place via the mating vertical Velcro strips (if applicable).
 - iii. Corner strips are designed to "wrap" around the corner of the enclosure

(Note: if you have too much or too little material to cover a particular area the overlap of the Velcro strips can be adjusted, though not less than a 1" overlap between adjacent panels is recommended)