

Installation Instructions

ANC-VB62

Material typically required to complete installation:
ANC-VB62, self-tapping screws or nails appropriate for substrate, furring strips (if the wall already exists) or other framing material (optional)

1. Determine the area to be covered.
2. Cut the material to the desired length
3. Using a mechanical fastener that is appropriate for the substrate, penetrate directly through the ANC-VB62 material into the substrate. Minimal securing is required since when you secure the sheetrock the ANC-VB62 will also be held in place.
 1. On wood substrates, roofing nails are often used as a fastener
4. Noise will "leak" through any small openings or cracks; therefore to maximize noise abatement, you must take great care to minimize any gaps or openings.
 1. If the entire length of the ANC-VB62 seam falls on a stud....
 - i. When putting one piece adjacent to the preceding piece make sure that the edges fit together snugly.
 - ii. Secure the next piece of ANC-VB62 to the wall or framing material.
 2. If section "1" above does not apply.
 - i. Make sure to overlap adjacent pieces of the ANC-VB62 at the seams by 2".
No further securing is required at the seam.
 - ii. Secure the next piece of ANC-VB62 to a stud.