

ROTOFAST SNAP-ON ANCHOR

Rotofast Snap-on Anchors are a secure and fast solution for acoustical panel installation. For ceilings or walls, the Rotofast Snap On anchor is the answer.

Everything you need to install a panel in 5
EASY STEPS.

Screw Rotofast Snap-On Anchors into the back of the panel using the Rotofast driver tool.

Insert marking plugs into the Snap-On anchors.

Push panel against wall to mark anchor locations

Screw ratchets to wall at marked locations. (#8 screws recommended)

Firmly push panel onto ratchets to complete installation.

Ask your panel manufacturer or Rotofast representative for recommended anchor locations and quantities per panel.

