



Manufacturing

- Once all project designs have been approved and finalized, the manufacturing phase begins.
- Our structures are fabricated at one of our four manufacturing facilities, depending on the structure type.
- After fabrication, the structure's components are either pre-assembled at our facility or packaged for shipment to the job site.

Shipping

- All Noise Control ships to all regions across the United States and has completed projects internationally.
- Customers have the option to arrange their own freight if preferred.
- Structures can also be picked up directly from our manufacturing facility.
- All Noise Control's shipping department carefully loads the materials onto a semi-trailer truck for delivery to the job site.

Site Preparation & Installation

- During the manufacturing phase, we recommend preparing the job site for the structure's installation.
- Once delivered, a specialized installation crew will assemble and install the structure.

