

SUSPENDED WALLS

ASSEMBLY INSTRUCTIONS: SUSPENDED WALLS— ALL AREAS

1. Layout and mark area to be enclosed.
2. While the hardware is on the ground, slide roller track (16 RT) through connectors to designated locations.
To make sliding roller track into connectors easier, squeeze ends of roller track together as you slide into the end of connector. Where two pieces of track meet inside a connector make sure to deburr the ends of the track and push the butting ends together so that they fit snugly. This prevents the rollers from getting stuck in a “pot hole” inside the connector. Be sure to see the track orientation detail to ensure that the enclosure is assembled as designed.
3. Now suspend all connectors, such as 16 BC's, at the proper height. (Refer to track layout drawing for locations).

NOTE: Threaded rod, chains, or other hanging mechanisms by others.

4. Install the acoustical curtain panels per the appropriate instructions.
5. Adjust hardware as necessary to accommodate curtains.
6. Line up existing holes or drill holes as necessary in track to accept set screws that lock into a hole in the track thru the track connector (use a 3/16 inch hex key).
7. Install 16 ES end stops in all open ends of track to prevent rollers from running out of track.





Right Angle Connector



In-Line Connector



3-Way Connector



Plain Curve



Track & Roller



Right Angle Connector



In-Line Connector



3-Way Connector



Plain Curve



Universal In-Line
Connector



End Stop



Right-Angle Connector



In-Line Connector



3-Way Connector



Plain Curve